


**For Your Convenience: This Northern
Lights File Is Shared By Diesel Parts Direct**



YOUR ONE STOP SUPERSTORE FOR DIESEL ENGINE PARTS

SHOP NOW



OM773LW2

For Models: M773LW and M773LW2

OPERATOR'S MANUAL

Marine Generators | Marine Diesel Engines | Land-Based Generators



LUGGER





— CALIFORNIA —
Proposition 65 Warning:

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

Northern Lights
4420 14th Avenue N.W.
Seattle, WA 98107
Tel: (206) 789-3880
Fax: (206) 782-5455

Copyright ©2009 Northern Lights, Inc.
All rights reserved. Northern Lights™, and
the Northern Lights logo are trademarks of
Northern Lights, Inc.

Printed in U.S.A.
PART NO.: OM773LW2 10/09



OPERATOR'S MANUAL

for Models

M773LW and M773LW₂

*Read this operator's manual thoroughly before starting to operate your equipment.
This manual contains information you will need to run and service your new unit.*

Table of Contents

INTRODUCTION	4
Models Included	4
Model Numbers	4
Serial Numbers	4
WARRANTY	5
SAFETY RULES	5
COMPONENT LOCATIONS	
M773LW Marine Generators.....	6
M773LW2 Marine Generators.....	7
PANELS	
Northern Lights Generator Sets	8 - 9
OPERATING PROCEDURES	
Break-in Period.....	10
Before Starting.....	10
Starting.....	10
Operating	10
Stopping	10
Shutdowns and Alarms	11
Spare Parts	11
SERVICING SCHEDULE CHART	12
SERVICING	
Lubrication - General.....	14
Checking Oil.....	14
SERVICING (CONTINUED)	
Oil Changes	14
Changing Oil Filter	14
Air Filter	15
V-Belts	15
Valve Clearances.....	15
Fuels - General.....	16
Fuel Filters	16
Bleeding the Fuel System	17
Injector Service.....	18 - 19
Injection Pump.....	19
Cooling System - General.....	19
Cooling System Flushing.....	20
Heat Exchanger	20
Raw Water Pump	20
Generator Ends	20
Electrical System - General	20
Glow Plugs.....	21
Booster Batteries.....	21
Battery Care	21
Winterizing / Out-of-Service	21
TROUBLESHOOTING	
Electrical	22
Engine	23 - 25
WIRING DIAGRAMS	
AC Electrical	26
DC Electrical	27 - 30

Proprietary Information

This publication is the property of Northern Lights, Inc.

It may not be reproduced in whole or in part without the written permission of Northern Lights, Inc.

© Northern Lights, Inc. All rights reserved. Litho U.S.A. Publication number OM773W2 10/09

Introduction

Servicing of marine engines and generator sets presents unique problems. In many cases boats cannot be moved to a repair facility. Marine engines cannot be compared to the servicing of automobiles, trucks or even farm equipment. Failures often occur in remote areas far from competent assistance. Marine engines are taxed far more severely than auto or truck engines; therefore, maintenance schedules must be adhered to more strictly.

Failures begin with minor problems that are overlooked and become amplified when not corrected during routine maintenance.

As operator, it is your obligation to learn about your equipment and its proper maintenance. This is not a comprehensive technical service manual. Nor will it make the reader into an expert mechanic. Its aim is to aid you in maintaining your unit properly.


Unit Identification

MODELS INCLUDED

This manual covers the operating instructions for:

M753W & W2 marine generator sets

Model numbers give the unit's application, block model, aspiration, and RPM



Serial Numbers



Your set has three serial numbers: ① an engine number stamped on the block, ② a generator plate, and ③ a generator set plate.

Use the serial number on the generator set plate when ordering parts or in correspondence. The generator set plate is found on the service side of the generator and resembles the drawing in Figure 1.

Figure 1: Generator set serial number plate.

A warranty registration certificate is supplied with your set. It entitles the original purchaser of our equipment to a warranty covering material or assembly faults. The extent of coverage is described in the Limited Warranty Statement. We recommend that you study the statement carefully.

NOTE: If the warranty is to apply, the servicing instructions outlined in this manual must be followed. If further information is needed, please contact an authorized dealer or the factory.

Safety Rules

CAUTION: *Accident reports show that careless use of engines causes a high percentage of accidents. You can avoid accidents by observing these safety rules. Study these rules carefully and enforce them on the job.*

- Never leave engine without proper security.
- Turn the coolant tank cap slowly to relieve pressure before removing. Add coolant only when the engine is stopped and cool.
- Mount a fire extinguisher near engine.
- Always disconnect the battery ground strap before making adjustments.
- Operate engines in properly ventilated areas.
- Keep trash and other objects away from engine.
- Escaping fluids under pressure can penetrate your skin. Use a piece of cardboard or wood, not your hands, to search for leaks.
- Avoid wearing loose clothing without a belt when working around engines.
- Do not oil or grease engine while it is running.
- Use caution in handling fuel. Never refuel a hot or running engine. Do not smoke while filling fuel tank or servicing fuel system. Clean up spilled fuel or oil to prevent potential fires.
- Keep your hands, feet, hair and clothing away from power-driven parts.
- Check for any loose electrical connections or faulty wiring.
- Engines should be operated only by knowledgeable, qualified personnel.
- Look completely around engine to make sure that everything is clear before starting.
- Do not operate an engine that isn't in proper working order. If an unsafe operating condition is noted, tag the set and control panel so others will also know about the problem.
- Provide first aid kits.



CAUTION: *This symbol is used throughout this book to alert you to possible danger areas. Please take special notice of these sections.*

Marine Generator Component Locations




Figure 1 & 2: M773LW with PX-309K2 generator

- | | | | | |
|--------------------------|-------------------------|---------------------------|--------------------------------|---------------------------|
| 1. Generator Control Box | 8. Fuel Injector | 15. Block Drain | 21. AC Circuit Breaker for AVR | 26. Starter |
| 2. Air Filter | 9. Stop Solenoid | 16. Fuel Inlet and Return | 22. DC Circuit Breaker | 27. Alternator |
| 3. Fuel Filter | 10. Injection Pump | 17. Oil Dipstick | 23. Expansion Tank | 28. HeatExchangerEnd Cap |
| 4. Fuel Lift Pump | 11. Lube Oil Fill, Side | 18. Lube Oil Filter | 24. Wet Exhaust Elbow | 29. Coolant Recovery Tank |
| 5. Crankcase Vent | 12. Seawater Pump | 19. Control Panel Plug | 25. Vibration Mount | |
| 6. Lube Oil Fill, Top | 13. Lube Oil Drain | 20. Generator Data Plate | | |
| 7. Coolant Fill | 14. Base frame | | | |

Marine Generator Component Locations




Figure 3 & 4: M773LW2 with PX-309K2 generator end.

- | | | | |
|--------------------------|-------------------------|---------------------------|----------------------------|
| 1. Generator Control Box | 7. Fuel Injector | 13. Seawater Pump | 20. Heat Exchanger End Cap |
| 2. DC Circuit Breaker | 8. Coolant Fill | 14. Fuel Inlet and Return | 21. Wet Exhaust Elbow |
| 3. Coolant Recovery Tank | 9. Lube Oil Fill, Top | 15. Oil Dipstick | 22. Vibration Mount |
| 4. Air Filter | 10. Stop Solenoid | 16. Lube Oil Filter | 23. Starter |
| 5. Fuel Filter | 11. Injection Pump | 17. Oil Drain | 24. Alternator |
| 6. Fuel Lift Pump | 12. Lube Oil Fill, Side | 18. Generator Data Plate | |
| | | 19. Expansion Tank | |

Control Panels




Figure 5: Series 1-B Generator Control Panel



Figure 6-a: Series 3 Generator Control Panel




Figure 6-b: Series 4 Generator Control Panel

1. SHUTDOWN BYPASS-PREHEAT SWITCH

There are two functions built into this switch:

1. Preheats the fuel before beginning the starting process. Press switch 10-20 seconds before attempting start-up.
2. Bypasses the safety shutdown feature during starting process. Keep switch engaged while starting engine and for 2 to 3 seconds afterwards, allowing oil pressure to build beyond shutdown set point.

2. ENGINE CONTROL SWITCH

To start the engine, hold this switch in the START position until the engine is running.

NOTE: Excessive cranking of marine sets equipped with water lift muffler systems can cause engine damage. See page 8.

After the engine starts, release the switch and it will return to RUN position. To stop the engine, hold the switch in the STOP position.

NOTE: The rocker switch is used on Series 1 panels only, and has a light that glows when the set is running.

3. HOUR METER

Keeps track of engine running time.

4. OIL PRESSURE GAUGE

Shows the oil pressure in the engine lubricating system.

5. WATER TEMPERATURE GAUGE

Registers the temperature of the cooling water.

6. D.C. VOLTMETER OR AMMETER

When the engine is stopped, the voltmeter indicates the condition of the battery. When the engine is running, the voltmeter indicates the voltage output of the alternator.

For Series 4 Control Panels Only:

7. A.C. VOLTMETER

Shows the generator output voltage.

8. FREQUENCY METER (Hertz)

The frequency meter indicates engine speed: 1200 or 1800 RPM (60 Hz), or 1500 RPM (50 Hz).

9. AMMETER SELECTOR SWITCH

Used to check each phase for load condition.

NOTE: Always leave this switch in the ON position while the unit is running.

10. A.C. AMMETER

Shows the generator load on each phase. The phase is selected with the Ammeter Selector switch (Item 9).




Figure 7-A: Series 7.0 through Series 7.6 Generator Control Panels.




Figure 7-B: Status Indicators for Series 7.0 through Series 7.6 Generator Control Panels.

1. SHUTDOWN BYPASS SWITCH

Manual Start Panels
(S-7.1 and S-7.3)

Hold the switch in the START position until the engine is running.

NOTE: Excessive cranking may cause engine damage.

After the engine starts, release the switch and it will return to the RUN position. To stop the engine, hold the switch in the STOP position.

Auto Start Panels
(S-7.0, S-7.2, S-7.4, S-7.5, and S-7.6)

When the switch is placed in the AUTO START position, the unit will automatically start when there is a drop in utility power.

2. OIL PRESSURE GAUGE

Shows the oil pressure in the engine lubricating system.

3. HOUR METER

Keeps track of engine running time.

4. ENGINE TEMPERATURE GAUGE

Registers the temperature of the coolant.

5. D.C. VOLTMETER

When the engine is running, the voltmeter indicates the voltage output of the alternator.

6. STATUS INDICATOR PANEL

Engine monitoring alarms and lamps for monitoring engine functions.

7. ALARM LAMP TEST AND RESET BUTTON

Press UP to test the indicator lights and press DOWN to reset the alarm.

8. A.C. VOLTAGE ADJUSTMENT RHEOSTAT

Voltage has been set at the factory and should only be adjusted by factory-trained personnel.

9. AMMETER SELECTOR SWITCH

Used to check each phase for load condition.

NOTE: Always leave this switch in the ON position while the unit is running.

10. FREQUENCY METER (HERTZ)

The frequency meter indicates alternator current frequency: 60 Hz (1200 or 1800 RPM), or 50 Hz (1500 RPM).

11. A.C. VOLTMETER

Shows the generator output voltage.

12. A.C. AMMETER

Shows the generator load on each phase. The phase is selected with the Ammeter Selector switch.

Operating Procedures

BREAK-IN PERIOD

1. The first 100 hours on a new or reconditioned engine are critical to its life and performance.
2. Constantly check the engine temperature and oil pressure gauges (sets with Series 3 or 4 panels).
3. Oil consumption is greater during break-in as piston rings take time to seat.
4. Break-In Oil Changes: Change engine oil and filter at 50 hours. Change oil and filter again at 100 hours, then at every 250 hours (consult Lubricants section for oil recommendation).

Operating Instructions:

Maintain at least a 75% load on your generator set for the first 100 hours. If this is not possible, maintain no less than a 50% load to ensure proper seating of the piston rings. Vary the load to help seat the rings.

BEFORE STARTING

1. Check the water level by removing the pressure cap from the expansion tank. In order to give the cooling water an opportunity to expand, the level should be about 1 in. (2.5 cm) below the filler cap sealing surface when the engine is cold.



CAUTION: Use protective clothing and open the filler cap carefully when the engine is warm to prevent burns.

2. Check the oil level in the crankcase with the dipstick. The oil level must be in the waffled area between maximum and minimum level on the stick. Never allow the level to go below this area. Always add the same viscosity of oil as is already in the crankcase.
3. Check the fuel tank level and open any fuel valves.
4. Close the sea-cock, check and clean the sea strainer and reopen the sea-cock.
5. Place the battery switch in the ON position.
6. **NOTE: The battery switch must always be kept ON while the engine is running. If the switch is turned OFF while the engine is running, the battery charging regulator could be ruined.**

STARTING

1. Hold the Shutdown Bypass-Preheat switch in the ON position for 10 to 20 seconds before starting a cold engine. Holding the switch too long can burn out the glow plugs. This step is not necessary if the engine is already warm.
2. While holding the Shutdown Bypass-Preheat switch in the ON position, push the Engine Control switch to the START position.
3. As soon as the engine starts, release both switches. Do not crank the starter for more than 10 seconds consecutively. If the engine fails to start with the first attempt, be sure that it has stopped completely for at least 30 seconds before re-engaging.
6. **NOTE: Excessive cranking of the starter on Marine sets equipped with a water lift muffler can cause engine damage. If the engine does not start after three 10-second cranks, remove the impeller from the raw water pump. This will prevent the muffler from filling with water and backfilling the exhaust line and engine. Once the engine starts, shut it off immediately and re-install the impeller. Re-start the engine and check the exhaust overboard outlet for gushes of water.**

OPERATING

1. Units with Series 3 and Series 4 Control Panels: check gauges often. Oil pressure must be above 15 PSI. The D.C. voltmeter should read between 11 and 15 volts at 80°F (25°C) ambient temperature. The coolant temperature gauge must be between 167°F and 194°F (75°C to 90°C). Check the A.C. voltage and frequency meters (Series 4 panel). If the gauges deviate from normal levels, shut down the generator set and investigate.
2. Let the unit run unloaded for a three to five minute warm-up period.
3. Add electrical load.

STOPPING

1. Remove electrical load from the generator set.
2. Move the Engine Control switch to the STOP position momentarily.
3. Shut off the seacock, fuel valve, and battery switch.

SHUTDOWNS AND ALARMS

1. Generator sets have shutdown systems to stop the engine in the event of high water temperature or low oil pressure.
 - a. Other alarms and shutdowns are available as optional equipment.

NOTE: Do not rely on your shutdown to the exclusion of careful gauge monitoring. Watching your gauges can prevent damage to the unit and dangerous power losses.

2. Do the following when your warning or shutdown system is activated:
 - a. Check the temperature gauge.
If above 205°F (96°C), shut off the engine immediately.
 - b. Use the Trouble Shooting Guide on page 22 to isolate the cause of the overheat.

! ***CAUTION: Do not remove the water fill cap of an overheated engine. Escaping high temperature steam can cause severe burns. Allow the engine to cool and then remove the cap slowly using protective clothing.***

- c. Make repairs. Restart your generator set after the temperature gauge registers below 200°F (94°C).
- d. Watch the temperature gauge regularly and turn off the unit if the temperature rises above 205°F (96°C) on Marine units. Repeat trouble-shooting.
3. If shutdown is activated and the temperature gauge shows temperature within normal temperature range:
 - a. Check the engine crankcase oil level.
 - b. If the oil level is low, fill with recommended lubricating oil and restart. Watch the oil pressure gauge carefully and shut off the engine if it does not show a normal reading (20-60 PSI) after a few seconds of operation.
 - c. If the oil level is normal, DO NOT restart the engine. Call your dealer for assistance.

SPARE PARTS

1. Northern Lights, Inc. recommends that you keep the following spare parts on hand for field service. The parts are available from your local Northern Lights dealer.
Marine models have optional “On-Board-Kits,” a handy box that contains the most common parts you will need.
2. All owners should have the following:
 - a. Primary and secondary fuel filter elements
 - b. Oil filters
 - c. Air filter
 - d. Alternator belt
 - e. Thermostat and gaskets
 - f. Seawater pump impeller & gaskets
 - g. Glow plug
 - h. Injector and washer
3. If your set is operating a long distance from a servicing dealer, add the following:
 - a. Complete set of injectors
 - b. Copper washers for injector change
 - c. Complete set of glow plugs
 - d. Fuel lift pump

Servicing Schedule Chart

The Servicing Schedule Chart below shows the service schedule required for proper maintenance of your generator set. More detailed coverage of each Service Point (SP) is listed on the page noted in the 'page' column.

DAILY:

- SP1 Check oil level in engine
- SP5 Check V-belt tension
- SP7 Check primary fuel filter
- SP13 Check coolant level
- Check sea strainer
- SP18 Check electrolyte in batteries

AFTER FIRST 50 HOURS:

- SP2/3 Change engine oil and filter
- SP6 Adjust valves

AFTER FIRST 100 HOURS:

- SP2/3 Change engine oil and filter

EVERY 250 HOURS:

- SP2/3 Change engine oil and filter
- SP4 Check air cleaner
- SP19 Check state of charge of batteries

EVERY 500 HOURS:

- SP8 Change primary fuel filter element
- SP9 Change secondary fuel filter
- SP21 Check condition of exhaust elbow

EVERY 1000 HOURS:

- SP4 Replace air cleaner
- SP6 Check valve clearances
- SP11 Check injectors
- SP17 Change impeller

EVERY 2500 HOURS:

- SP12 Check fuel injection pump
- SP14 Check and flush cooling system
- SP15 Check and clean heat exchanger

SERVICE POINT	PAGE	OPERATION	DAILY	50 Hours	250 Hours	500 Hours	1000 Hours	2500 Hours
SP1	10 & 14	ENGINE: Check oil level	●					
SP2	14	Change engine oil	1) 5)	●	●			
SP3	14	Change lube oil filters	1) 5)	●	●			
SP4	15	Check air cleaner, change element @ 1000 hrs. 1) 4) 5)			●			
SP5	15	Check V-belt tension	●					
SP6	15	Check valve clearances	1) 2)				●	
		FUEL SYSTEM:						
SP7	16	Check primary filter (Racor)	2) 3)	●				
SP8	16	Change primary filter element (Racor)	2) 3)			●		
SP9	16	Change secondary fuel filter	1) 3)			●		
SP10	17	Bleed the fuel system	3)					
SP11	19	Check injectors	1) 3) 6) 7)				●	
SP12	19	Check fuel injection pump	7)					●
		COOLING SYSTEM:						
SP13	10 & 19	Check coolant level		●				
SP14	20	Check and flush cooling system						●
SP15	20	Check and clean heat exchanger						●
SP17	20	Change impeller in raw water pump	1) 3)				●	
SP21	20	Change condition of exhaust elbow	1) 3)			●		
		ELECTRICAL SYSTEM:						
SP18	21	Check electrolyte level in batteries		●				
SP19	21	Check condition of batteries with hydrometer	1) 4)		●			
		OUT OF SERVICE:						
SP20	21	Winterizing or out-of-service	3)					

1) Perform all maintenance once a year even if hour level has not been reached.

2) Consult manufacturer's maintenance schedule, note on chart.

3) Whenever necessary.

4) More often if necessary.

5) After first 50 hours, then at 100 hrs., then every 250 hrs.

6) Clean injection nozzles every 1500 hours.

7) For EPA emission standards fuel nozzle needs to be cleaned every 1500 hours, the fuel nozzle and fuel pump need to be cleaned, adjusted, or repaired every 3000 hours, and the quality guarantee for these parts is 1500 hours or 2 years.

Service Record Notes

Servicing

LUBRICATION - GENERAL

1. Use only clean, high quality lubricants stored in clean containers in a protected area.
2. These lubricants are acceptable:
 - a. API Service CC/CD/CE single viscosity oils.
 - b. API Service CC/CD/SF multi-viscosity oils.
3. Use the proper weight oil for your average operation temperature.

Air Temperature	Single Viscosity	Multi-Viscosity
Above 32°F (0°C)	SAE 30W	SAE 15-40W
-10 to 32°F (-23 to 0°C)	SAE 10W	SAE 10-30W
Below -10°F (-23°C)	SAE 5W	SAE 5-20W

Figure 8: Lube Oils

4. Some increase in oil consumption may be expected when SAE 5W and SAE 5-20W oils are used. Check oil level frequently.
5. Never put additives or flushing oil in crankcase.

SP1. CHECKING OIL LEVEL

1. Check the oil level in the crankcase with the dipstick. The oil level must be in the waffled area on the stick. Never allow the level to go below this area. Follow the lubrication recommendations above.

SP2. OIL CHANGES

1. The set is delivered with special break-in oil. Change the engine oil and oil filter after 50 hours of operation. Use Service CC 30 weight oil during the first 100 hours.
2. Change the oil and filter again at 100 hours using the oil recommended in Figure 8. After this, change oil and filter every 250 hours.
3. During intermittent cold weather operation, change oil every 100 hours or six weeks, whichever comes first.
4. Change oil at any seasonal change in temperature when a new viscosity of oil is required.
5. Change oil when engine is warm.
6. Dispose of waste oil in an approved manner.
7. Never use a flushing oil.
8. Loosen the clamp on the oil change tube. Remove cap. Drain oil. Replace the cap and tube.
9. Refill engine with recommended oil.
10. Engine capacity with new oil filter is:
 - 773LW - 4.2 quarts (4 liters)
 - 773LW2 - 4.75 quarts (4.9 liters)

SP3. CHANGING LUBE OIL FILTER

1. Change the lube oil filter every 250 hours.
2. Use a filter wrench to remove old filter. Dispose of filter in approved manner.
3. Make sure the gasket from the old filter is removed and discarded. Clean mount face.
4. Spread a thin film of engine oil on the rubber gasket on the new filter and screw it on nipple until gasket meets the sealing surface.
5. Using hands only – no wrench – tighten filter one-half turn farther. Overtightening can do damage to filter housing.
6. Fill engine with recommended oil. Start engine and check for leakage. Stop engine, wait 3 minutes, and check oil level. Add additional oil if necessary.
7. Oil filter part numbers are:
 - 773LW - #140516190
 - 773LW2 - #24-02001

SP4. AIR CLEANER

1. Inspect air cleaner every 250 hours. In dusty conditions, check more often.
2. If dirty, wash element in soapy water. Rinse and dry thoroughly before re-installing.
Replace if necessary. Part numbers are:

M773LW – #24-22003

M773LW2 – #24-28602

3. ***NOTE: Make absolutely sure no impurities enter the engine while changing the element. Do NOT run the engine with the air cleaner removed.***

SP5. V-BELTS

1. Check the tension and wear on the V-belt daily.
2. Use your thumb to press on the belt at the midpoint between the crankshaft and alternator pulleys. The tension is correct if the belt can be depressed about $\frac{3}{16}$ in. (5 mm).




Figure 9: Valve Adjustment

SP6. VALVE CLEARANCES

1. Adjust valve clearance after 1000 hours or as needed.
2. Valve adjustments should be done after the cylinder head bolts have been re-tightened. Engine should be cold and NOT running.
3. To bring the No. 1 cylinder to top dead center in the compression stroke, align the timing mark; the top mark of the crank pulley with that of the timing gear case. Remove the rocker arm cover and turn the crankshaft forward and backward. If the inlet and exhaust valves of the No. 1 cylinder do not move it is in top dead center position. When the valves move, or rock, turn the crankshaft one full turn and align the top mark of the crank pulley with the top mark of the timing gear case.
4. Loosen the lock nut and adjust the clearance between the rocker arm and valve guide of both the intake and exhaust valves with the adjustment screw (Figure 9). Clearance on both intake and exhaust valves should be 0.008 in. (0.2 mm).
5. Repeat steps 3 and 4 for each cylinder. Each set of valves must be adjusted individually.
6. Replace the rocker arm cover. Tighten cover nuts to 5 - 8 ft/lbs (0.8 - 2.3 kg/m).




Figure 10: Timing Mark

Servicing

FUELS - GENERAL

1. Use only clean, high quality fuels of the following specifications, as defined by ASTM designation D975 for diesel fuels:
 - a. Use grade no. 2 diesel at ambient temperatures above freezing 32°F (0°C).
 - b. Use grade no. 1 at ambient temperatures below freezing and for all temperatures at an altitude of above 5,500 ft. (1500 meters).
2. Use fuel having less than 1% sulphur (preferably less than 0.5%).
3. The cetane number should be a minimum of 45.
4. DO NOT use these unsuitable grades of fuel:
 - a. Domestic heating oils, all types.
 - b. Class B engine.
 - c. Class D domestic fuels.
 - d. Class E, F, G or H industrial or marine fuels.
 - e. ASTM-D975-60T No. 4-D and higher number fuels.
5. Storing fuel:
 - a. Keep dirt, scale, water, and other foreign matter out of fuel.
 - b. Avoid storing fuel for long periods of time.
 - c. Fill the fuel tank at the end of each day's operation. This will reduce condensation.

SP7-9. FUEL FILTERS

1. Your generator set should have a primary fuel filter installed. We recommend the Racor brand of fuel filter-water separators.
 - a. Check the primary fuel filter daily as recommended by the filter manufacturer. Empty the collection bowl as necessary.
 - b. Change the element as often as necessary or every 500 hours.
 - c. If the bowl fills with water, change the primary and secondary element immediately.
2. Change secondary fuel filter every 500 hours or as necessary.
 - a. Remove the spin-on filter by turning it counterclockwise with a filter wrench. Fill the new cartridge with fuel and install it after applying engine oil to gasket surface. Screw on until the gasket surface comes into contact with sealing surface of filter base. Then, tighten it two-thirds of a turn by hand. Do not overtighten.
 - b. Fuel filter part numbers are:

773LW AND 773LW2: #24-52020

SP10. BLEEDING THE FUEL SYSTEM



CAUTION: Escaping diesel fuel under pressure can penetrate skin causing serious personal injury.

Before disconnecting lines be sure to relieve all pressure. Before applying pressure, be sure all connections are tight and lines, pipes and hoses aren't damaged. Fuel escaping from a very small hole can be almost invisible. Use a piece of cardboard or wood, rather than hands, to search for suspected leaks. If injured by escaping fuel, see a doctor at once. Serious infection or reaction can develop if proper medical treatment isn't administered immediately.




Figure 11: M773LW Fuel System.

1. The fuel system is self-bleeding. However, any system may need manual bleeding when:
 - a. A new fuel filter is installed;
 - b. The engine has run out of fuel;
 - c. The fuel lines, injection pump or any other fuel system component has been removed and installed.
2. Loosen bleed bolt “A” (Figure 11) on top of the filter. Pump hand primer “B” on fuel lift pump until pure fuel (no bubbles) escapes from bleed bolt “A”. Tighten bleed screw “A”.
3. Loosen bleed screw “C”. Pump hand primer “B” until pure fuel (no bubbles) escapes. Then tighten bleed screw “C”.
4. If the engine does not start after the above bleeding process, loosen a fuel line at the injector while cranking the engine with the starter motor until pure fuel escapes. Then tighten the connection. Do each line **one-at-a-time**.
5. After the engine has started, use a piece of cardboard to look for fuel leaks.

Servicing




Figure 12: Remove delivery line flare nuts.




Figure 16: Unscrew injector.




Figure 13: Remove delivery lines.




Figure 17: Remove and replace copper sealing washer.




Figure 14: Remove return line nuts.



Figure 18: Reinstall injector. Torque to proper tightness.




Figure 15: Remove return line.

SP11. INJECTOR SERVICE

1. Injectors should be checked every 1000 hours. Check should be made by a Northern Lights dealer or local injection repair station.



CAUTION: Escaping diesel fuel under pressure can have sufficient force to penetrate the skin causing serious personal injury. If injured by escaping diesel fuel, see a doctor at once.

2. Injector removal:

- a. Clean loose dirt from around the injectors and the fuel lines.
 - b. Relieve high pressure in the fuel lines by loosening the delivery line flare nuts at each injector (Figure 12).
 - c. Remove delivery lines by disconnecting from injectors and injection pump (Figure 13). Remove all lines as an assembly; do not remove the spacers. Cover the ends of the lines, the injector inlets and injection pump outlets to keep dirt out.
 - d. Remove the return line retaining bolts (Figure 14). Remove the return line (Figure 15).
 - e. Unscrew and remove the injectors (Figure 16).
- NOTE: Do not use pry bars to remove injectors from cylinder head.***
- f. After removing the injectors, discard the copper sealing washers from the injector hole in the head (Figure 17). Cover holes to prevent dirt and debris from entering the cylinders.

3. Injector installation:

- a. Install a new copper sealing washer in each injector hole (Figure 17).
 - b. Screw in injector and tighten to 43 or 50 ft/lbs (6 to 7 kgm) (Figure 18).
- NOTE: Overtightening can damage injector.***
- c. Install return line using new copper sealing above and below each connection. Tighten return line retaining bolts to 22 - 30 ft/lbs.
 - d. Install delivery lines. Leave loose at injectors for bleeding.
 - e. Pump hand level on fuel pump to fill lines. Tighten lines at injectors. Start engine and check for leaks using a piece of paper or cardboard.

DO NOT use hand to check for leaks.

SP12. INJECTION PUMP

1. Since operating conditions may vary considerably, it is difficult to give a definite interval for checking the injection pump. But as a rule, pump settings, maximum speed, idle speed and exhaust smoke should be checked after every 2500 hours of operation. Service of the fuel injection pump should only be done if checks indicate pump malfunction.
2. Black smoke can be an indication of pump malfunction. Before servicing the pump, check other possible causes:
 - a. Check cleanliness of air filter.
 - b. Check valve clearances.
 - c. Clean and check injectors.
3. Any repair which involves disassembly of the injection pump must be carried out by specially trained mechanics with the proper tools and test equipment.

NOTE: All warranties on the engine become null and void if the injection pump seals are broken by unauthorized persons.

COOLING SYSTEM - GENERAL

NOTE: Be sure to close the sea-cock before working on the engine cooling system.



CAUTION: The cooling water in the engine reaches extremely high temperatures. You must use extreme caution when working on hot engines to avoid burns. Allow the engine to cool before working on the cooling system. Open the filler cap carefully, using protective clothing when the engine is warm.

SP13. CHECK THE COOLANT LEVEL

1. Check the coolant level each day before starting the engine. Check the water level by removing the pressure cap from the expansion tank or radiator. In order to give the cooling water an opportunity to expand, the level should be about 1 in. (2.5 cm) below the filler cap sealing surface when the engine is cold.
2. The pressure valve in the filler cap releases when the pressure is approximately 7 PSI (0.5 bar). Use a cap pressure tester to check cap if you suspect it is faulty.

Servicing

SP14. COOLING SYSTEM FLUSHING

1. Flush the cooling system every 2500 hours or every 12 months, whichever comes first.
 - a. Remove expansion tank cap and drain engine block.
 - b. Open block drain cock.
Remove plug in lower left side of heat exchanger tank.
 - c. Pour clean water into expansion tank until water coming from drains is free of discoloration and sediment. Let water drain completely. Close drains and refill with recommended mixture.
2. Coolant Specifications:
Use 50% water / 50% ethylene glycol antifreeze mix. Antifreeze mixture is recommended as a good year-round coolant, but not methyl alcohol based antifreeze because of its effect on non-metallic components and its low boiling point. Also, anti-freeze with high silicate should not be used as it could cause silica gelation problems.
3. Check hoses and connections and repair any leakage.

SP15. HEAT EXCHANGER

1. Clean the heat exchanger core once a year or after 2500 hours of operation.
2. Drain expansion tank and heat exchanger.
3. Remove heat exchanger end covers and remove core.
4. Clean the inside of exchanger core tubes using a metal rod. Flush, inspect and clean again if necessary.
5. Reassemble. Fill the cooling system, start the engine and check for leaks.

SP17. RAW WATER PUMP

1. Change the seawater pump impeller every 1000 hours, or as needed.
2. Remove the pump end cover. Pry out the impeller using needle-nose pliers or two screwdrivers.
Be sure you remove all pieces of failed impeller.
NOTE: Place some kind of protection under the screwdrivers in order not to damage the pump housing.
3. Clean the inside of the housing.
4. Press in the new impeller and place the sealing washers in the outer end of the impeller center if this has not already been done.
5. Replace the cover using a new gasket.
NOTE: Make sure that there is always an extra impeller and cover gasket in reserve on board.

GENERATOR ENDS

The maintenance and operation recommendations for the generator end are in a separate Owner's Manual. If you do not have one of these manuals, contact your local Northern Lights dealer.

ELECTRICAL SYSTEM - GENERAL

1. Never switch battery switch off or break the circuit between the alternator and batteries while the engine is running. Regulator damage can result.
2. Do NOT reverse the polarity of battery cables when installing the battery.
3. When welding on the unit, disconnect the regulator and battery. Isolate the leads.
4. Disconnect the battery cables when servicing the D.C. alternator.
5. Never test with a screwdriver, etc., against any terminal to see if it emits sparks.
6. Do not polarize the alternator or regulator.
7. A D.C. circuit breaker protects your control panel and wiring harness. It is located in the side of the generator junction box.

GLOW PLUGS

1. Each cylinder is supplied with a glow plug which serves to heat the combustion chamber.
2. To check the glow plugs, loosen the current carrying flat wire between the plus-poles of the glow plugs (Figure 19). Connect a D.C. test bulb between the plus-pole of the battery and the plus-pole of the glow plug. If the bulb lights up, the glow plug is functioning properly.
3. Check all glow plugs and replace any faulty ones.





Figure 19: Glow plugs.

BOOSTER BATTERIES



**CAUTION: Battery gas can explode.
Keep all flames and sparks away from batteries.
Battery electrolyte is sulfuric acid diluted, which
can burn or stain body or clothes.**

1. Before changing or using booster batteries, check battery electrolyte level. Add distilled water if necessary.
2. Booster and main batteries must have the same voltage rating.
3. First, connect positive (+) terminal of booster battery to positive (+) terminal of main battery. Then, connect negative (-) terminal of booster battery to ground on the engine block (see Figure 20).
4. Remove booster battery after starting engine.
5. Sealed batteries: See manufacturer charging and booster instructions.



*Figure 20:
Battery connections.*

SP 18-19. BATTERY CARE

1. Check electrolyte level daily. Add distilled water to manufacturer's recommended level.
2. Batteries, cables and cable terminals should be checked and cleaned every 100 hours. Clean corrosion with a water and baking soda solution. Flush with clean water. Tighten terminals and grease them to inhibit corrosion.
3. Check the battery condition with a hydrometer every 250 hours.

SP20. WINTERIZING / OUT-OF-SERVICE

1. Generator sets:
 - a. Drain fresh water and seawater cooling systems completely. Remember to shut off seacock before opening drain cocks.
 - b. Drain water supply lines and wet exhaust line.
 - c. Loosen the seawater pump cover and drain pump.
 - d. Fill the fuel tank or add biocide as per manufacturer's instructions.
 - e. Seal the air cleaner inlet, exhaust opening, crankcase breather pipe, and fuel tank vent with plastic bags and tape.
 - f. Store the set in a dry, protected place. If unit must be stored outside, be sure it is well protected with a cover.
 - g. Change the crankcase oil and filter.
 - h. Loosen the alternator belt.
 - i. Disconnect and clean battery. Remove to warm storage place if possible.
 - j. Clean outside of unit. Paint any scratched or chipped surfaces. Put corrosion preventative on all exposed metal surfaces.

Troubleshooting

DC ELECTRICAL SYSTEM

PROBLEM	POSSIBLE CAUSE	RECOMMENDATION(S)
Battery Will Not Charge	Loose or corroded connections Sulfated or worn out batteries Loose or defective alternator belt	<ul style="list-style-type: none"> • Clean and tighten battery connections. • Check specific gravity of each battery. • Check electrolyte level of each battery. • Adjust belt tension. • Replace belt.
Starter Inoperative	Check DC circuit breaker Loose or corroded connections Low battery output Defective electrical system ground wire:	<ul style="list-style-type: none"> • If the breaker is tripped, reset it. • Clean and tighten loose battery and harness plug connection. • Check specific gravity of each battery. • Check electrolyte level of each battery. • Repair or replace.
Starter Cranks Slowly	Low battery output Check specific gravity of each battery Check electrolyte level of each battery Crankcase oil too heavy Loose or corroded connections	<ul style="list-style-type: none"> • Battery is too small. • Battery cables are too small. • Replace battery if necessary. • If low, fill cells with distilled water. • Fill with oil of appropriate viscosity. • Clean and tighten loose connections.
Entire Electrical System Does Not Function	Check DC circuit breaker Faulty connection Sulfated or worn out batteries	<ul style="list-style-type: none"> • If breaker is tripped, reset it. • Clean and tighten battery and harness plug connections. • Check specific gravity and electrolyte level of each battery.

If you cannot correct problems with these procedures, see your **Northern Lights** dealer.

Troubleshooting

ENGINE PROBLEM	POSSIBLE CAUSE	RECOMMENDATION(S)
Engine Hard to Start or Will Not Start	Improper starting procedure No fuel Low battery output Excessive resistance in starting circuit Crankcase oil too heavy Improper type of fuel Water, dirt or air in fuel system Clogged primary fuel filter element Clogged secondary fuel filter element Dirty or faulty injection nozzles Fuel injected but no ignition	<ul style="list-style-type: none"> • See starting section of this manual. Take special note of Bypass Switch operation. • Check level of fuel in fuel tank. • Check electrolyte level and condition. • Clean and tighten all battery connections. • Use oil of proper viscosity. • Consult fuel supplier and use proper type of fuel for operating condition. • Drain, flush, fill and bleed system. • Clean or replace filter element. • Replace filter element. • Have your dealer check injection nozzles. • Glow plug malfunction • Injection timing not correct • Low cylinder compression pressure
Engine Runs Irregularly or Stalls Frequently	Below normal engine temperature Clogged primary fuel filter element Clogged secondary fuel filter element Water or dirt in the fuel system Dirty or faulty injection nozzles Air in fuel system Improper type of fuel Low idle, not stable	<ul style="list-style-type: none"> • Remove and check thermostat. • Clean or replace filter element. • Replace secondary filter element. • Drain, flush, fill and bleed system. • Have your dealer check injection nozzles. • Inspect clamps and hoses on suction side of fuel pump for air leak. • Consult fuel supplier and use proper type of fuel for operating condition. • Uneven cylinder compression
Lack of Engine Power	Intake air restriction Clogged primary or secondary fuel filter element Improper type of fuel Overheated engine	<ul style="list-style-type: none"> • Service air cleaner. • Clean or replace filter element. • Consult fuel supplier and use proper type of fuel for operating conditions. • See “Engine Overheats” in next category.

Troubleshooting

ENGINE PROBLEM	POSSIBLE CAUSE	RECOMMENDATION(S)
Lack of Engine Power, <i>continued</i>		
	Below normal engine temperature	<ul style="list-style-type: none"> • Remove and check thermostat.
	Injection pump fuel supply insufficient	<ul style="list-style-type: none"> • Air mixing in injection pump. • Fuel filter clogged.
	Improper valve clearance	<ul style="list-style-type: none"> • Reset valves. Best done by dealer.
	Dirty or faulty injection nozzles	<ul style="list-style-type: none"> • Replace injectors. Best done by dealer.
	Cylinder compression pressure low, cylinder compression pressure leakage	<ul style="list-style-type: none"> • Adjust valve clearance • Adjust nozzle holder alignment • Check cylinder bore wear
Engine Overheats		
	Low coolant level or cooling system defective	<ul style="list-style-type: none"> • Fill tank or radiator to proper level. • Check hoses for loose connections and leaks. • Fan belt slipping
	Keel cooling tubes have been painted	<ul style="list-style-type: none"> • Remove paint from tubes.
	Cooling system needs flushing	<ul style="list-style-type: none"> • Flush cooling system.
	Defective thermostat	<ul style="list-style-type: none"> • Remove and check thermostat.
	Defective temperature gauge	<ul style="list-style-type: none"> • Check water temperature with thermometer and replace gauge if necessary.
	Water pump impeller worn/broken	<ul style="list-style-type: none"> • Check impeller and replace if necessary.
Engine Knocks		
	Insufficient oil	<ul style="list-style-type: none"> • Call your dealer.
	Injection pump out of time	<ul style="list-style-type: none"> • Call your dealer.
	Below normal engine temperature	<ul style="list-style-type: none"> • Check your thermostats. • Check water temperature to see if temperature gauge is working properly.
	Engine overheating	<ul style="list-style-type: none"> • See “Engine Overheating” section.
High Fuel Consumption		
	Improper type of fuel, or fuel leaking	<ul style="list-style-type: none"> • Use correct fuel for temperature. • Check installation or tightening.
	Clogged or dirty air cleaner	<ul style="list-style-type: none"> • Service air cleaner.
	Improper valve clearance	<ul style="list-style-type: none"> • See your dealer.
	Injection nozzles dirty	<ul style="list-style-type: none"> • See your dealer.
	Injection pump timing off	<ul style="list-style-type: none"> • See your dealer.
	Engine overloaded	<ul style="list-style-type: none"> • Check load usage.
	Engine not at proper temperature	<ul style="list-style-type: none"> • Check your thermostats. • Check water temperature with thermometer and replace gauge if necessary.


If you cannot correct problems with these procedures, see your **Northern Lights** dealer.

Troubleshooting

ENGINE PROBLEM	POSSIBLE CAUSE	RECOMMENDATION(S)
Below Normal Engine Temperature	Thermostats not working properly Temperature gauge not working properly	<ul style="list-style-type: none"> Check thermostats. Check water temperature with thermometer.
Low Oil Pressure	Low oil level Clogged filter and strainer or worn bearings and oil pump Improper type of oil Partially plugged oil filter	<ul style="list-style-type: none"> Fill crankcase to proper level. Repair or replace Drain and fill crankcase with correct oil. Replace filter.
High Oil Consumption	Break-in period Crankcase oil too light Oil leaks	<ul style="list-style-type: none"> Oil consumption decreases after break in. Use proper viscosity oil. Check for leaks in lines around gaskets and drain plug.
Engine Emits Black or Gray Exhaust Smoke	Clogged or dirty air cleaner Defective muffler (back pressure too high) Improper fuel Injection nozzles dirty Engine timing off	<ul style="list-style-type: none"> Service air cleaner. Have dealer check back pressure. Use correct fuel for temperature. See your dealer. See your dealer.
Engine Emits White Smoke	Improper fuel Cold engine Defective thermostat Engine timing off	<ul style="list-style-type: none"> Use correct fuel for temperature. Warm up engine to normal operating temperature. Remove and check thermostat. See your dealer.

If you cannot correct problems with these procedures, see your **Northern Lights** dealer.

Wiring Diagrams



NOTES: 1. ALL A.D.E. INSTALLED CONDUCTORS ARE TO BE TYPE

2. FOR REMOTE VOLTAGE ADJUST, KNEAD STYLUS ON JUMPER AND SPLICE INTO PURPLE LEADS.

3. SET SW2 FOR CURRENT APPLICATION, (50 OR 60 HZ).

4. AVR INPUT SENSING SW1 IS TO BE SET TO THE 200V POSITION FOR ALL VOLTAGES EXCEPT DIRECT VOLTAGE.

4. DETELE NEUTRAL CONDUCTOR (AND JUMPER IF PRESENT),
IF LOWER VOLTAGE IS NOT REQUIRED
100V POSITION ALL POLARITIES EACH! STRAIGHT
100V POSITION APPLICATIONS. IF
NOT POSITIONED, USE
100V POSITION

5. LINE ONE (HIGH LEG) TO BE MARKED ORANGE WHEN NEUTRAL IS PRESENT IN ACCORDANCE WITH ARTICLE 115 OF THE NATIONAL ELECTRICAL CODE.
10. SEE SWIS PER APPLICATION IF REMOTE VOLTAGE ADJUST RHEOSTAT IS USED.
11. TERMINAL BLOCKS WILL NOT ACCOMMODATE LARGER GAU

215-8 OF THE NATIONAL ELECTRICAL CODE.
6. MARINE GENSETS ARE GROUNDED BY CUSTOMER, AT
CUSTOMER'S DISCRETION. INDUSTRIAL GENSETS ARE
CONDUCTORS, IF REQUIRED, REMOVE AFFECTED LEADS
TERMINAL BLOCK(S) AND MAKE CONNECTIONS USING BO-
LOCK WASHER AND NUT. ISOLATE BY WRAPPING WITH

TO BE GROUNDED IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE AND ANY APPLICABLE LOCAL CODES.

7 THICK HIDDEN (DASHED) LINES INDICATE CUSTOMER EARTHING CONNECTIONS.

ELECTRICAL TAPE.

12. THE DOUBLE DELTA CONFIGURATION REQUIRES THE AVR REWIRED AS FOLLOWS: DISCONNECT LEADS 3 AND 4 FROM

1. UNION INDUSTRY (UNION INDUSTRY CO., LTD.) SUPPLIED OR CONNECTED MAIN OUTPUT CORDS, SIZING TO BE DETERMINED PER INSTALLATION.
2. CONNECT LEAD 3 TO AVR TERM. 4 (THROUGH C.B.). LEAD 4 TO AVR TERM. 5. DISCONNECT LEAD E5 FROM ISOLATE, CONNECT AVR TERMINAL E5 TO MAIN OUTPUT.

TERM. "W", USING A RED AWG 14 LEAD (SEE NOTE 1).


卷之三

**M773LW and M773LW2, 12 & 4 Lead Generators
with AVR DST-100-2FAK**


B-8280E

111


Wiring Diagrams



DC Engine Wiring Diagram
M773LV and M773LV2, 12 Volt Standard Ground
B-8659A




Wiring Diagrams



DC Engine Wiring Diagram
M773LW and M773LW2, 24 Volt Standard Ground
B-8661C

Wiring Diagrams





4420 14th Ave. NW., Seattle WA 98107

Tel: (206) 789-3880 • 1-800-762-0165 • Fax: (206) 782-5455

Northern Lights and Lugger are registered trademarks of Northern Lights, Inc.

© 2009 All rights reserved. Litho USA.